














**ITEM NAME/NOM D'ITEM: LISSE RECTANGULAR DINING TABLE**  
**ITEM #/NO. ITEM: 110500**


## PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(5)
 x1	 x2	<p>A.  M6 x 30MM x16</p> <p>B.  M6 x 35MM x2</p> <p>C.  M6 x 50MM x2</p> <p>D.  M6 x 80MM x2</p>
(3)	(4)	
 x1	 x2	<p>E.  1/4 x22</p> <p>F.  M5 x 32MM x8</p> <p>G.  DIA 12 x 40MM x2</p> <p>H.  M4 x1</p>


## ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE




III.




IV.




V.




VI.



VII.



 Assembled

Please use the attached adjustable footglides to level the table on an uneven surface.